



First time configuration

Before you start:

Open Read-a-Card and activate a PC-based license or attach a licensed reader

About

1 Choose one or more actions to take when a card is presented

Action

- Place ID in keyboard buffer
- Place ID in clipboard
- Play sound
- Run command or script
- Launch URL
- Make HTTP request

Options:

- a. Restrict the card types that will trigger an action
- b. Restrict the reader types that are monitored
- c. Write details of cards and readers detected to file
- d. Choose to ignore duplicate card presentations

Card Type

Reader Type

Logging

Settings

2 Choose what card data to read and the format to expect and use

Format

- Card Serial Number (UID)
- HID iClass / Prox / Mobile ID
- MIFARE Sector Decoder
- DESFire Decoder
- NFC Decoder
- Paxton Net 2 Compatible Decoder
- Custom Format

- Hex standard
- Hex reversed
- Decimal standard
- Decimal reversed

- 26-bit
- 37-bit
- Corporate 1000

3 Prepare for use

Minimise application to tool tray



Options:

- a. Display details for the most recent card read
- b. Lock this configuration with a password

Status

Lock

If you need help to set up or use Read-a-Card, beyond what is contained in our guides, please contact our support team.

Website: readacard.com/support Email: support@readacard.com

Telephone: UK and Europe +44 (0) 1428 685861, North America and Latin America +1 888-262-9642 or +1 562-262-9642